

1966 Fairlane



WIRING DIAGRAM MANUAL

1966 Ford 6 & V8





GREEN-BLACK
RED-BLACK
GRN-WHITE
WHITE-BLUE
BLUE-YELLOW
BLK-YELLOW
PINK
RED-GREEN
YELL-BLACK
GRN-RED
BLK-YELL
WHT-RED
RED-WHITE
RED-GREEN
WHITE-GREEN
RED-BLUE
BROWN
GREEN-RED
WHT-GREEN
LOW BEAM
HIGH BEAM
DIRECTION SIGNAL
PARKING LIGHT
HORN
ALTERNATOR REGULATOR
WINDSHIELD WIPER MOTOR
WINDSHIELD WASHER PUMP
WHITE
BLACK
BLUE
RED
GREEN-BLACK
BLACK-WHITE
OIL PRESS. SWITCH
CONDENSER
BREAKER
DISTRIBUTOR
8 CYL.
TEMP. GAUGE (ENG. UNIT)
BLUE-RED
GRN-YELLOW
BLK-GREEN
FUSE BLOCK
ORANGE
STOP LIGHT SWITCH
BACKUP LIGHT SWITCH
NEUTRAL SAFETY SWITCH
COIL
STARTER
ALTERNATOR
6 CYL.
BLACK-RED
BLACK-YELLOW
BLACK-WHITE
WHITE-BLUE
BLUE-YELLOW
BLOWER MOTOR
YELLOW
BROWN
STARTER RELAY
BATTERY
6629


1966 Fairlane




WIRING DIAGRAM MANUAL



1966 FAIRLANE INSTRUMENT PANEL





1966 FAIRLANE EXTERIOR LIGHTING, TURN SIGNALS AND HORNS




FOR MODEL 71 ONLY

1966 FAIRLANE EXTERIOR LIGHTING, TURN SIGNALS AND HORNS







1966 FAIRLANE INTERIOR LIGHTING



SINGLE SPEED WINDSHIELD WIPER




2-SPEED WINDSHIELD WIPER AND WASHER




WIRING COLOR CODE	
615 57 28	BLACK
56 42	BLUE
63	RED
950 58 95	WHITE
96	ORANGE-BLACK
297	BLACK-GREEN
763	ORANGE-WHITE
941	BLACK-WHITE
951	GREEN-BLACK
●	SPLICE

1966 FAIRLANE WINDSHIELD WIPERS AND WASHERS, SINGLE AND TWO SPEED




WIRING COLOR CODE	
57	BLACK
181	ORANGE
268	RED
269	BLUE
297	BLACK-GREEN
913	YELLOW


1966 FAIRLANE HEATER AND DEFROSTER




1966 FAIRLANE EMERGENCY WARNING FLASHER




FRONT SPEAKER WITH AM RADIO




REAR SPEAKER WITH AM AND AM-FM RADIO RECEIVER






WIRING COLOR CODE	
19	BLUE-RED
297	BLACK-GREEN


1966 FAIRLANE RADIO RECEIVER AM, AM-FM AND SPEAKERS






WIRING COLOR CODE	
140	BLACK-RED
21	YELLOW
297	BLACK-GREEN
520	VIOLET
450	GREEN
●	SPLICE


1966 FAIRLANE SEAT BELT WARNING



1966 FAIRLANE IGNITION, STARTING, CHARGING AND GAUGES—6-AND 8-CYLINDER



WIRING COLOR CODE	
102	WHITE
103	WHITE-RED
104	BLUE-ORANGE
105	RED-WHITE
106	BLUE
●	SPLICE



1966 FAIRLANE OVERDRIVE